



По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70

Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93



Water Pressure Reducing Control Valves

Hydraulic Pressure Reducing Water Pressure Reducing Control Valves
Model NO.: 100X, 200X, 300X, 400X, 500X, 600X, 700X, 800X, 900X

Temperature: Low Temperature

Valve Seat: Diaphragm Type

Material: Cast Iron QT450

Nominal Diameter: Dn50-350 mm

Trademark: THT

Specification: ISO

HS Code: 848180

Certification: RoHS, ISO

Connection: Flange

Structure: Diaphragm

Nominal Pressure: Pn16

Transport Package: Export Wooden Packing

Original place: wenzhou.



Hydraulic Pressure Reducing Water Pressure Reducing Control Valves 100X, 200X, 300X, 400X, 500X, 600X, 700X, 800X, 900X

Specification:

For BS 4504 BS EN1092-2 PN10 / PN16/ PN25 flange mounting.

Face-to-Face dimension conforms to ISO 5752 / BS EN558.

Epoxy fusion coating.

A float control valve maintains a preset water level in a reservoir or a water tank. In its simplest form a float valve is fitted with a float designed to control the top water level in the tank. A dual level float can be fitted to control the level between top and bottom levels. Float control valves can be remotely operated with an addition of a solenoid or a hydraulic relay.

Typical Applications

A top level float valve is typically used where water tanks are required to be full and where the tank is not filled up by a dedicated pump, a dual level float can be fitted in order to minimise pump starts and stops.

Manufactured to ISO 9001;

Available Valve sizes DN32~600;

Available MPA 1.5~2.5;

Available Up to -10°C~ 80°C;

Face-to-Face dimension conform to BS EN 558.

Flange drill is suitable for BS EN 1092-2 PN10/ PN16.

Test as ISO 5752.

Working pressure:

10 bar / 16 bar for PN10 / PN16.

Fast response time;

Fast shutdown on command;

Full unrestricted valve operation on tank filling;

Easily adjustable level settings

Low supply pressure options

Accurate Level Control

Completely Automatic Operation

Simple Operation

Maintenance Free

Material list:

Part	Material
Body/Bonnet	Ductile iron / WCB
Disc	WCB / Stainless steel
Diaphragm	EPDM
Shaft	Stainless steel
Pilot / Ball valve / Pipe	Brass / Stainless steel

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70

Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93